

# Signholders (iPad Stand™)

Applicable Products:

IPEC

1. Remove acrylic cover using small tamper-proof key provided. Place tablet inside and reassemble unit (fig. A).

*Note: If ball joint loosens on back, use the large tamper-proof key to retighten it securely.*

